



Maintenance and Tips

Here is a list of items you will want to keep on hand with your new dance floors:

1. **Gloves (cotton)**
2. **Marine grease**
3. **Cordless drill (with ratchet torque drive)**
4. **#2 Phillips screw driver**
5. **Clean rags**
6. **Goof Off brand remover (in the yellow can)**

1. **Gloves:**

There are sharp edges. Anyone handling the panels at anytime should always be wearing gloves. To help prevent a static charge it is recommended that the gloves are made of cotton. It is also recommended that anyone handling the acrylic floor panels should not be wearing any wool or silk clothing. These materials tend to build a static charge when rubbed against the acrylic surface.

2. **Marine Grease:**

All new floors come with brand new never been used plugs and sockets. This means they may tend to be stiff and fit tight at first. To fix this it is recommended to apply a little marine grease on all the connections.

3. **Cordless Drill:**

It is ok to use a power driver to secure the screws as long as it has a ratchet torque drive set at low torque. No screws should be secured until all the screws have been started. See the manual for more details.

4. **Phillips Screwdriver:**

All screws for the dance floor system accept a #2 Phillips head.

5. **Clean Rags:**

All that is needed to clean the dance surface is water and a clean rag. Never use anything abrasive. Whatever does not come off with water can be removed with "Goof Off" remover and a clean rag.

6. **Goof Off:**

We have tested many cleaners and recommend Goof Off brand professional strength remover (in the yellow can). It can be used to clean any parts of the floor panels and trim. Simply wet a clean rag with Goof Off and wipe.