

REMOTE CONTROL MODE CHART

MODE	FUNCTION	BRIGHTNESS	SPEED	DISCRIPTION
1	RGBW	Adjustable	Fixed	Red, Green, Blue, White fade in and out in a set cycle.
2	Seven Color Flash	Adjustable	Adjustable	Flash Red, Green, Blue, Yellow, Magenta, Cyan and White.
3	Disco	Adjustable	Adjustable	Red, Green, Blue, White, Purple and Yellow cycle in rotation with random transitions.
4	Red Fade In and Flash	Adjustable	Adjustable	Red brightens to full brightness, then flashes 3 times.
5	Green Fade In and Flash	Adjustable	Adjustable	Green brightens to full brightness, then flashes 3 times.
6	Blue Fade In and Flash	Adjustable	Adjustable	Blue brightens to full brightness, then flashes 3 times.
7	Multi-Color Mix	Adjustable	Adjustable	Multiple colors fade and flash randomly and actually cycle thru all 9 modes starting with Mode 8.
8	Six Color Fade	Adjustable	Adjustable	Red, Green, Blue, Yellow, Magenta and Cyan fade in and out.
9	White Only Fade	Adjustable	Adjustable	White continuously fading in and out.